




# Which Panel Do I Need?

	EN54 Approved	No of Zones	No of Sounder Circuits	Aux Relays	Outputs	Outputs Programmable	Class Change Input	Twin Wire	Twin Wire per Zone	Networkable	Repeater Panels	One Man Walk Test	Disable Feature	Set Output Delays	False Alarm Modes	Non Latching Zones	Short Circuit as Alarm Zones	View Event History
 <b>ECLIPSE</b>	✓	2 or 4	2	1 x Cmn Fire 1 x Cmn Fault	1 x Cmn Fire 1 x Cmn Fault	✗	✓	✓	✗	✗	✗	✓	✓	✗	1	✓	✓	✗
 <b>EXCEL-EN</b>	✓	2,4,6 8 & 12	2 - 8L = 2 8 & 12 models = 4 (max = 6 using high spec cards)	1 x Cmn Fire 1 x Cmn Fault  (additional relay on high spec zone cards)	1 x Cmn Fire 1 x Cmn Fault	✓	✓	✓	✓	✓	✓	✓	✓	✓	3	✓	✓	✓
 <b>EXCEL-32</b>	✓	16, 24 & 32	4	1 x Cmn Fire 1 x Cmn Fault	1 x Cmn Fire 1 x Cmn Fault	✓	✓	✗	✗	✓	✓	✓	✓	✓	3	✓	✓	✓